

EYECLICKER

Hazard Analysis

SFWR ENG 4G06 / MECHTRON 4TB6 GROUP 8

Adam Gordon 400036676 Bowen Yuan 400005913 Jacky Chan 400015317 Jeffrey Sun 400022051 Leo Li 400032949 Tongfei Wang 001437618

Contents

1	Rev	rision History	2
2	Pur	pose	3
	2.1	Document Purpose	3
	2.2	Assumption	3
	2.3	Scope	3
	2.4	Methods and Techniques	3
	2.5	Definitions	3
3	Cor	nponents	3
	3.1	Eye-Tracking System	3
	3.2	Cursor System	3
	3.3	Voice System	4
	3.4	Mouse Action System	4
	3.5	Calibration System	4
	3.6	AI System	4
	3.7	GUI System	4
4	Safe	ety Consideration	4
	4.1	Eye-Tracking System	4
	4.2	Cursor System	4
	4.3	Voice System	5
	4.4	Mouse Action System	5
	4.5	Calibration System	5
	4.6	AI System	5
	4.7	GUI System	5
5	Cor	relation Between Hazard Functions and Requirements	6
6	\mathbf{FM}	EA Worksheet	7
	6.1	Hazards Considered out of Scope	7
	6.2	Boundary Diagram	7
	6.3	Failure Modes and Effect Analysis Table	7

1 Revision History

Date	Revision	Authors		
Jan 13, 2019	0	All group members		
Feb 29, 2020	1	All group members		

2 Purpose

2.1 Document Purpose

The Hazard Analysis document's purpose is to find the possible hazards that are present in the design of the Eye-Clicker and then implements precautions to mitigate the risk.

2.2 Assumption

The hazards that are discussed in this document are risks that the system introduces that cause unintended effects. Because there are no physical dangers the Eye-Clicker can bring upon the user, the hazards discussed in this document will not be referring to physical hazards that the user of the system may face.

Besides, hazards caused by improper use of our program are not included in our document such as users are sitting further than 60cm away while using our program. Moreover, software or hardware setup errors like monitor malfunctioning are not our concern.

2.3 Scope

The project will be based around tracking the user's eye movements to move the cursor. The project will also allow for voice control to activate mouse actions, including but not limited to moving the cursor, left-clicking and right-click. Moving the cursor will be achieved through image processing, more specifically, human eye recognition.

2.4 Methods and Techniques

The project consists of several modules that may have failure based on their own use. The technique we use is splitting the system to small pieces of module and analyzing every part of the program. We went through each of our individual components and assessed the most impactful failures that could greatly affect the system. The impact of failures include both deduction of performance and ability to keep running.

2.5 Definitions

Landmark Points: Points around the user's eyelids to be detected and recorded by the Eye-Tracking System

Pupil Points: The points in the center of the user's pupils to be detected and recorded by the Eye-Tracking System

Gaze Position: The spot that the user is looking at on the display

3 Components

3.1 Eye-Tracking System

Responsible for detecting and recording the landmark points and pupil points.

3.2 Cursor System

Responsible for receiving predicted cursor position and moving the cursor to the corresponding location as well as sending the cursor's current location up receiving the signal

of getting the cursor position.

3.3 Voice System

Responsible for detecting voice commands from the user and initiating the response.

3.4 Mouse Action System

Responsible for executing mouse click actions.

3.5 Calibration System

Responsible for matching the user's pupil and the cursor's location

3.6 AI System

Responsible for predicting the user's desired cursor position based on a machine learning algorithm

3.7 GUI System

Responsible for interacting with users, such as displaying objects that convey information and representing actions

4 Safety Consideration

4.1 Eye-Tracking System

Software Issues:

- Not able to detect the user's landmark points and/or pupil points.
- Filtering webcam frame data can malfunction and crashes the entire system

Hardware Issues:

- Web camera crashes
- Web camera disconnects

4.2 Cursor System

Software Issues:

- Not able to move the cursor to the location predicted by the AI model
- Not able to provide the cursor's current location in real-time

Hardware Issues:

• Software is not able to interact with the OS to move the cursor

4.3 Voice System

Software Issues:

- Not able to distinguish the user's voice under a noisy environment
- Not able to recognize what the user says
- The required pause between voice commands inhibits the user from making quick consecutive voice commands

Hardware Issues:

• The user's voice is not captured or recognized due to broken microphone

4.4 Mouse Action System

Software Issues:

• Performs unintended cursor actions

Hardware Issues:

• Software is not able to interact with the OS to perform mouse clicks

4.5 Calibration System

Software Issues:

- Not able to save the calibration data
- User does not follow correct instructions resulting in a bad calibration that lowers accuracy

Hardware Issues:

None

4.6 AI System

Software Issues:

- Not able to predict the cursor location within the error margin
- The program crashes while making predictions

Hardware Issues:

CPU is unable to compile the software

4.7 GUI System

Software Issues:

- The GUI crashes while unhandled actions being executed by users.
- The GUI displays undesired feedbacks or ambiguous information while actions being executed by users.
- The GUI is unable to provide actions to allow users to connect each module's interface.

Hardware Issues:

• The GUI has a sizing issue caused by the different resolutions of the monitor.

5 Correlation Between Hazard Functions and Requirements

 $Group\ 8$

Hazard Function:	Performance Requirement:		
	Performance Requirement 1		
	Performance Requirement 2		
F1: Initiate EyeClicker	Performance Requirement 3		
	Performance Requirement 4		
	Performance Requirement 5		

Hazard Function:	Performance Requirement:
F2: Calibration	Performance Requirement 1

Hazard Function:	Performance Requirement:
	Performance Requirement 1
F3: Eye Detection	Performance Requirement 2
	Performance Requirement 3

Hazard Function:	Performance Requirement:		
F4: Gaze position on screen detection	Performance Requirement 1		

Hazard Function:	Performance Requirement:
F5: Move cursor	Performance Requirement 1

	Hazard Function:	Performance Requirement:
	F6: Record Voice Commands	Performance Requirement 4
		Performance Requirement 5

Hazard Function:	Performance Requirement:		
F7: Perform Voice Commands	Performance Requirement 4		

6 FMEA Worksheet

6.1 Hazards Considered out of Scope

- Hardware wiring fails and causes one or more components not being able to function
- Eye-Tracking algorithm recognizing something else as user's eye (images on his T-shirt, or anything similar to an eye in the background) rather than the users
- User issuing consecutive voice commands too quickly which results in one long unusable voice input
- Accidentally deleting files or shutting down your computer due to any combination of misuse and poor tracking accuracy

6.2 Boundary Diagram




Figure 1: Boundary Diagram

6.3 Failure Modes and Effect Analysis Table

Severity of failure:

Very severe — program failed to initiate property, modules not working, program crash, etc.

Severe — cursor position prediction is inaccurate, cannot identify user's command by voice control, etc

Minor — delays between eye movement and cursor movement, delays between performing user's voice command and request

Function	Failures	Unacceptabl e Event	Severity of Failure	Cause of Failure	Likelihood of occurrence	Recommended Action	Likelihood of failure detection
F1: Initiate EyeClicker	Software unable to start	EyeClicker does not run	Very severe	Computer setup has errors that prevent the execution of EyeClicker	Very unlikely	Resolve the error messages that occur when running EyeClicker	Very likely
F2:	Software unable to calibrate	The eye-tracking will not be accurate	Severe	Software bug or system error	Moderately unlikely	Reattempt the calibration or restart EyeClicker	Moderately likely
Calibration	Calibration did not train correctly	The eye-tracking will not be accurate	Severe	The user did not follow instructions precisely or the data didn't train properly in the AI algorithm	Moderately unlikely	Repeat calibration and follow the instructions with more accuracy.	Very unlikely
F3: Eye	Camera stream unable to connect to EyeClicker	No video stream to process	Very severe	The camera is not connected properly, or the software cannot recognize the camera source.	Very unlikely	Check the camera connection and test if the camera is operational.	Moderately likely
Detection	Cannot detect pupil and landmark points	Unable to track eye movements	Very severe	Resolution of video stream is not clear, or user's eyes are not sufficiently visible	Moderately unlikely	Change to a better camera or have the user sit closer to the camera.	Moderately likely

Figure 2: FMEA Table

F4: Gaze Detection	AI position prediction is inaccurate	Cursor will be moved to seemingly random locations	Severe	AI model is not optimized for the environment	Neither likely nor unlikely	Perform another calibration to improve the accuracy	Very likely
F5: Move Cursor	Cannot move the cursor on the screen	Unable to move the cursor to the predicted location	Very severe	OS not supported, permission not granted, or software unable to connect to the OS's cursor module.	Very unlikely	Check if there are any OS settings that prevent unrecognized apps from accessing the cursor	Moderately likely
F6: Record Voice Commands	Unable to record voice commands	Will not be able to analyze and perform voice commands	Very severe	Unable to detect microphone	Neither likely nor unlikely	Check the system to see if there is an existing audio input source. Attempt to connect EyeClicker to that audio input source	Neither likely nor unlikely
F7: Perform	Does not perform action upon valid voice command	Cannot perform mouse clicks when requested	Very severe	Converting voice command text failed or text comparison resulted in a wrong decision.	Moderately unlikely	Repeat the command with more volume and more clarity	Neither likely nor unlikely
Voice Commands	Performs invalid action or actions on invalid commands	Mouse clicks without the predetermine d command	Severe	Converting voice command text failed or text comparison resulted in a wrong decision.	Very unlikely	Terminate EyeClicker and restart the software	Very likely

Figure 3: FMEA Table Continued